



単位:mm

受口 呼径	主 管 (下流)						枝 管						
	記号	d <sub>1</sub>	d <sub>2</sub>	d1及びd2 の許容差	D	d	l	d <sub>1</sub>	d <sub>2</sub>	d1及びd2 の許容差	D	d	l
		基準寸法	基準寸法					基準寸法	基準寸法				
75		89.45	88.65	±0.30	97.0	77.2	40	89.45	88.65	±0.30	97.0	83.0	40
100		114.55	113.55	±0.35	124.0	98.8	50	114.55	113.55	±0.35	124.0	107.0	50
75X 50		89.45	88.65	±0.30	97.0	77.2	40	60.35	59.75	±0.30	67.0	56.0	25
100X 75		114.55	113.55	±0.35	124.0	98.8	50	89.45	88.65	±0.30	97.0	83.0	40

単位:mm

呼径	記号	d'	l'	Z <sub>1</sub>	Z <sub>2</sub>	Z <sub>3</sub>	L <sub>1</sub>	L <sub>2</sub>	L <sub>3</sub>
75		90	80	48.0	55.0	48.0	88.0	135.0	88.0
100		115	100	62.0	71.0	62.0	112.0	171.0	112.0
75X 50		90	80	34.0	41.5	48.0	74.0	121.5	73.0
100X 75		115	100	48.0	57.0	62.0	98.0	157.0	102.0

図名

TNS 90° T 寸法図

東栄管機株式会社